VoxStar-II Bluetooth Wireless Headset

Pairing Instructions:

Note: if your computer has internal Bluetooth built-in, you will need to disable it from the Windows Control Panel, so that it does not conflict with the BT 2 USB adapter. Or if you choose not to use the BT 2 adapter and use your internal computer Bluetooth (if your computer is so equipped), then you can just pair the headset directly to your Windows computer and not use BT 2 adapter.

Best performance is obtained using the BT 2 adapter.

1) Plug BT 2 USB adapter into the computer's USB port
2) Hold down the power button on the headset for 30 seconds until it is completely off.
3) Wait a few seconds, and then press and hold the power button on the headset for 20 seconds until it comes up in pairing mode, denoted by a fast flashing
4) Allow 1 minute for the headset to pair to the BT 2. Both units will now blink slower, indicating that they are paired together.

If you have any questions or need assistance, please call us.
Phone Numbers:
Toll-Free (USA and Canada): **1 (866) 254-0714**
Outside the USA: 1 (727) 939-8853
(Florida, USA)
Fax: 1 (810) 821-6940
Hours of Operation:
Sales: Monday-Friday, 9:00 AM - 6:30 PM Eastern Time
Tech Support: Monday - Friday 9:00 AM - 6:00 PM, Saturday 11AM - 1PM.
Email Addresses:
Sales Department: **sales@startstop.com**
Technical Support Department: **techsupport@startstop.com**

HTH Engineering, Inc

Tarpon Springs, FL 34688
Web: http://www.StartStop.com
Email: Webmaster@StartStop.com
Call: (866) 254-0714 (toll free)
Fax: (810) 821-6940