



HTH Engineering, Inc.
Tarpon Springs, FL 34688
Tel: 866-254-0714 Fax: (810) 821-6940
Web: <http://www.startstop.com>

INSTALLATION INSTRUCTIONS

Samson Wireless Microphone for Pathology Use

Your system has been preconfigured, integrated and tested prior to shipping.

- 1. Plug in the power adapters as shown in the user manual in the box.**
- 2. Turn the power on the receiver base unit to “ON”**
- 3. Set the volume level to somewhere between 10 o’clock and 12 o’clock position.**
- 4. Make sure the channel is set to 0 –on the base unit (if not, repeatedly press the “SELECT” button until you scroll to “0”. This channel should result in a green light lighting up on the base unit “READY” light, if the microphone itself is already on. Read the manual if you’re not sure.**
- 5. Charge up the headset microphone with the magnetic charger adapter connector included for at least a couple of hours.**
- 6. Connect the black HTH engineering custom attenuation adapter cable from the back of the receiver unit to the jack marked MIC on the Olympus digital recorder.. Use caution- do not flex this cable repeatedly, especially at the splice connection where the attenuation components are located!**



HTH Engineering, Inc.
Toll Free 1 866 254 0714 x1 TECHNICAL SUPPORT
jwinner@startstop.com



THANK YOU!!